



DESCRIPTION

TAG 200 brings a new standard to the market around transitional adhesives. TAG 200 is a very aggressive, high tack transitional adhesive that installs like a pressure sensitive adhesive but firms as it cures. Engineered for the installation of a wide variety of resilient and modular floor covering types, TAG 200 is solvent free and offers excellent moisture, pH, and plasticizer resistance.



pH
 7-12



RH
 Up to 99%



Dry Time
 30+ min



Working Time
 12 hrs



Cure Time
 24 hrs



Foot Traffic
 Immediate
 Occupancy



Rolling Loads
 24 hrs

Approved Floor Covering

- Luxury Vinyl Tile (LVT)
- Luxury Vinyl Plank (LVP)
- Modular Carpet Tile Approved Backings: non-PVC, Polyolefin, Felt; up to 99% RH and pH:12, PVC; limited to 95% RH and pH:10
- Vinyl Composite Tile (VCT)
- Vinyl sheet and Fiberglass Reinforced Sheet Flooring (Sheet Goods limited to 90% RH and pH:10)
- Solid Vinyl Tile and Plank

Limitations

- For bare concrete substrates only
- Not for exterior installations
- Not for use to encapsulate asbestos
- Not for use when moisture exceeds 4% per ASTM F2659, or Relative Humidity of concrete slab exceeds 99% (ASTM F2170)
- Not for use where hydrostatic pressure exists
- Do not use if substrate pH is greater than or equal to 12
- Concrete slab must be a minimum of 5° above dew point
- Substrate temperature must be between 60°-90° F – 30-65% RH
- Do not install over chemically abated substrates
- Do not install flooring in wet adhesive over a non-porous substrate
- Do not install over adhesive residue or cutback adhesive
- Do not allow product to freeze
- Do not use with dimensionally unstable floor coverings
- Do not use over concrete substrates which have been treated with silicates, either topical or entrained

Suitable Substrates

- Concrete slabs (at least 28 days old)
- Cement-based self-levelers/patching compounds
- APA underlayment grade plywood and OSB (per manufacturer recommendation)
- Cement backer board
- Cement terrazzo (properly prepared with waxes and surface finishes removed)
- Existing Vinyl Composite Tile (VCT) free of wax and sheet flooring
- Properly primed gypsum underlayments that meet the ASTM F2419 requirements for compressive strength
- Fully secured cork underlayments
- Concrete and radiant heated subfloors (should be turned off 24hrs prior to installation)
- Radiant heated substrates – Maximum 85° F

**PLEASE CONSULT TAG ADHESIVES'
TECHNICAL DEPARTMENT FOR SUBSTRATES
NOT LISTED AT 682-704-7547**

Substrate Testing

- RH: 99% [ASTM F2170]
Precautionary Note: TAG 200 is not a moisture mitigation system and should not be used as one. It simply means that the adhesive will hold up under high moisture conditions, however floor covering may have adverse effects.
- pH: Between 7-12 [ASTM F710]

PRECAUTIONARY NOTE: THIS PRODUCT DOES NOT FORM A MOISTURE VAPOR BARRIER AND WILL NOT PROTECT FLOORING FROM MOISTURE DAMAGE

Surface Preparation

NOTE: FOLLOW FLOORING MANUFACTURERS GUIDELINES. SUBSTRATES MUST BE PREPARED PER ASTM F710 BUT NOT LIMITED TO THE FOLLOWING:

- Concrete floors must be dry, smooth, solid, structurally sound and level.
- Substrates should be clean and free of dust, dirt, oil, grease, paint, curing agents, concrete sealers; topical or entrained, loosely bonded toppings, adhesive residue, loose particles, and any other substance or condition that may prevent or reduce adhesion.
- Fill all surface cracks, grooves, depressions, non-moving joints with moisture resistant patching and self-leveling compounds.
- Substrate, adhesive and floor covering must be acclimated in an enclosed building with HVAC in operation for 48 hours prior, during, and after the installation is complete.
- Ambient temp must be between 60°-90° Fahrenheit.
- Relative humidity must be between 30-65% during and following installation.
- When installing over radiant heated subfloors, heat should be turned off 24 hours before, during, and after installation. When turning radiant heat back on, do so in 5° increments per hour to desired heat temperature. Heat temperature should not exceed 85° Fahrenheit.

Installation Instructions

Follow flooring manufacturer's guidelines for layout, design and any special precautions for installation.

DISCLAIMER: FOLLOW THESE INSTRUCTIONS COMPLETELY OR DO NOT USE THIS PRODUCT.

- 1) *** If unfamiliar with a product, always perform a bond test. Simply spread a small sample of adhesive and apply desired flooring product in adhesive to ensure desired bond is achieved. ***
- 2) After surface preparation, spread adhesive using recommended trowel or roller as needed for desired flooring type.

DRY-SET PSA (porous and non-porous substrate)

- After spreading, wait 30-60 minutes for adhesive to flash off. Adhesive will lighten and will not transfer to fingertips when touched.
- Working time: Up to 12 hours depending on ambient temperature and absorbency of substrate.
- Only apply as much adhesive as can be installed within a 12 hour period. Protect the adhesive from dust and debris, which will inhibit proper bond and decrease tack.

SEMI-WET SET (porous substrates only)

- After spreading, wait 15-25 minutes for adhesive to flash off installing sheet vinyl into semi-wet adhesive with transfer to floor covering backing.
 - Working time: 20-30 minutes depending on ambient temperature.
- 3) After installation, roll floor with 75-100lb roller to ensure proper adhesive transfer.
 - Sheet goods: Roll from the center towards the perimeter to allow expelling of trapped air.
 - Check flooring after 2 hours and roll again if necessary.

** Wait 6 hours before heat welding on sheet goods**

** Wait 48 hours before wet mopping, stripping, or finishing the floor**

NOTE: Foot traffic may be allowed immediately when installing into dry adhesive. For installations into wet or semi-wet adhesive, allow 12 hours before traffic.

Required Tools & Coverage

TAG 200
TRANSITIONAL PRESSURE SENSITIVE ADHESIVE

Floor Covering	Trowel Recommendation	Estimated Coverage
LVP, LVT, VCT, SVT, Modular Carpet Tile	1/16" x 1/32" x 1/32" U Notch	220 - 260 sqft/gallon
Homogeneous and Heterogenous Sheet Goods (porous substrate), double stick pad to substrate	1/16" x 1/16" x 1/16" Square Notch	150 - 180 sqft/gallon
Resilient Sheet (fiberglass) and Carpet Tile	3/8" Short Nap Paint Roller	Up to 360 sqft/gallon

Cleanup

- While wet, use a cloth and soapy water to remove wet adhesive
- When material is dry, use denatured alcohol or appropriate adhesive remover
- Always check for compatibility on a piece of scrap flooring
- Clean tools with water while the adhesive is still fresh/wet

Storage

- This product should be stored at temperatures between 50°-90° degrees Fahrenheit.
- This product has a shelf life of 2 years

Disclaimer: Users should determine suitability of this information or product for their own purpose or application. Manufacturer is not responsible for the misuse of this product. This adhesive is not a moisture barrier and should not be installed/treated as such. This adhesive is not a substrate moisture sealer and does not form a protective barrier and is only warranted to maintain an adhesive bond when used over substrates specified in this document. ASTM 2659 impedance readings that exceed 4% may void the warranty.

Exclusively made by Lighthouse Adhesives



PROFESSIONAL FLOORING SUPPLY

PO Box 7558, Fort Worth, TX 76111
800-772-2706 | www.accesspfs.com

PROFESSIONALFLOORING
SUPPLY